

GENERAL MAINTAINERS

Optimate2

12V 0.8A
4 STEPS

TM-420

Advanced
24-7-365 battery
maintenance

Smart voltage & current control

Charges flat batteries from 2 Volt



WEATHERPROOF CASE
with WALL MOUNTS

1

Low Volt
Start (2V)

2

Controlled
CHARGE



3

OPTIMIZE

4

OptiMate
maintenance



CHARGING AMPS	0.8A
USE	INDOOR / OUTDOOR t°min: -4°F / -20°C
SAVE	Low Volt Start 2V
IDEAL FOR	  3 - 96Ah
CABLE ACCESSORIES	